
Thermostat





- Control the temperature of multiple heaters within the same room
- Customise start/stop times
- Set multiple temperatures throughout the day
- Enable child lock functions
- Multiple heating settings and Boost and Ecomode options
- Simple and quick installation
- Battery operated: x4 AAA batteries









Thermostat



The Screen Display

Window Mode

 \Diamond

Defrost Mode

Child Lock

OFF

000

2.4G Signal Display

WiFi Signal Display

GURRENT

Battery Capacity Display

Current Room Temperature

TARGET

Setting Target Temperature

Temperature Display

@G »RH **©**[F

°C/°F: Switch The Unit



Turn On The Heater

BOOST



Boost Mode STR/END: Start Timer/Close Timer, e.g. 8.

1 is ECOMODE LOW, 2 is ECOMODE MED, 3 is ECOMODE HIGH

TIMER

Timer Mode

Time Display

7 8 9

SUN MON TUE WED THU FRI SAT

Number Indicate: how many you can control the device in this thermostat.

Week Display

Dimensions

Size (LxHxW)

85 x 85 x 24 mm

Weight

<1KG

