

Instruction leaflet

MAINS SUPPLY DOORBELL 240V

Cat. N°. C3504

To be read in full before installation and kept for future reference

Ensure the power supply is switched off before fitting, servicing or changing the doorbell. This fitting must be installed in accordance with the current edition of the IEE Wiring Regulations. If in doubt, contact a qualified electrician.

Installation Instructions

- Switch off the electricity at the fuse box before proceeding with the installation
- Remove the front cover of the doorbell by removing the screw underneath
- · Mount the back section of the doorbell to the wall using fixing screws
- Connect a 240V supply to the live and neutral terminals
- Connect appropriate bell wire (not supplied) to the unbiased terminals inside the doorbell (see diagram), and route to the position of the bell push
- · Remove the front cover of the bell push
- Connect the other end of the bell wire to the terminals of the bell push
- Bell push seal must be fitted to the rear of the bell push, with the cable routed through "+" shaped slot. Failure to fit this seal will affect the guarantee.
- · Secure the bell push in its position
- · Replace the front cover of the bell push
- · Replace the front cover of the doorbell, and secure in place with the screw
- Switch on the electricity at the fuse box by replacing the relevant fuse or switching on the circuit breaker after completing the installation.

Please note

• For longer cable runs, cable with a larger cross sectional area is advised, eg.13 strand speaker flex

Specification

Supply Voltage 240V~ Door Bell Type Dimensions (mm) 128(H), 128 (W), 44 (D) Kit Contents

Mechanical Sounder

Door Bell, Bell Push and Bell Push Seal

DETA ELECTRICAL COMPANY LIMITED Kingsway House, Laporte Way, Luton, Bedfordshire LU4 8RJ England Tel: +44 (0) 1582 544 500

S06 INS0017 NPD 0547 0417